

nijoste1: Programming Barcodes for DS4608

Configuration name in Utility : nijoste1
Last Modified : 06-Mai-25
Windows Filename : Config File_DS4608_nijoste1_2025.05.06.scncfg
Plug-in Name : DS4608-STANDARD SR MODELS-014
Report Type : Only parameters changed from defaults shown



nijoste1: Programming Barcodes for DS4608

Configuration name in Utility : nijoste1
Last Modified : 06-Mai-25
Windows Filename : Config File_DS4608_nijoste1_2025.05.06.scncfg
Plug-in Name : DS4608-STANDARD SR MODELS-014
Report Type : Only parameters changed from defaults shown



Set Factory Defaults

Cable Connection Settings

USB

USB Device Type	USB HID Keyboard
Emulate Keypad	Disable
Emulate Keypad with Leading Zero	Disable
Quick Keypad Emulation	Disable

Symbology (bar code type) Settings

Aztec

Aztec	Disable
-------	---------

Codabar

Codabar	Disable
---------	---------

Code 128

Code 128	Disable
ISBT 128	Disable
GS1-128 (UCC/EAN-128)	Disable

Code 39

Code 39	Disable
---------	---------

Code 93

Code 93	Disable
---------	---------

nijoste1: Programming Barcodes for DS4608

Configuration name in Utility : nijoste1
Last Modified : 06-Mai-25
Windows Filename : Config File_DS4608_nijoste1_2025.05.06.scncfg
Plug-in Name : DS4608-STANDARD SR MODELS-014
Report Type : Only parameters changed from defaults shown



DataMatrix

GS1-Datamatrix	Enable
----------------	--------

GS1 Databar

GS1 Databar Omnidirectional	Disable
-----------------------------	---------

GS1 Databar Limited	Disable
---------------------	---------

GS1 DataBar Expanded, GS1 DataBar Expanded Stacked	Disable
--	---------

Interleaved 2 of 5

Interleaved 2 of 5	Disable
--------------------	---------

UPC EAN

UPC-A	Disable
-------	---------

EAN-13/JAN13	Disable
--------------	---------

UPC-E	Disable
-------	---------

EAN-8/JAN8	Disable
------------	---------

Modify Data- Advanced Data Formatting

Suffix 1 Enter

7

0

1

3

Scan Data Transmission Format <Data><Suffix 1>

nijoste1: Programming Barcodes for DS4608

Configuration name in Utility : nijoste1
Last Modified : 06-Mai-25
Windows Filename : Config File_DS4608_nijoste1_2025.05.06.scncfg
Plug-in Name : DS4608-STANDARD SR MODELS-014
Report Type : Only parameters changed from defaults shown



General Parameter Settings

Power

Low Power Mode	Enable Low Power Mode
Time Delay To Low Power	10 seconds

System

keyboard country type	German
Country Code Page	ISO-8859-15 - Latin 9

Beeper

Beeper Volume	Medium
Configuration File	nijoste1

Firmware:

CAAEIS00-002-R03